

# Cortex-M33 Cycle Model

Version 9.6

## User Guide



# Cortex-M33 Cycle Model

## User Guide

Copyright © 2017 Arm Limited (or its affiliates). All rights reserved.

### Release Information

### Document History

Issue	Date	Confidentiality	Change
0902-00	31 August 2017	Non-Confidential	First release
0906-00	17 November 2017	Non-Confidential	Release with 9.6

### Non-Confidential Proprietary Notice

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of Arm. **No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.**

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether implementations infringe any third party patents.

THIS DOCUMENT IS PROVIDED “AS IS”. ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, Arm makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, third party patents, copyrights, trade secrets, or other rights.

This document may include technical inaccuracies or typographical errors.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word “partner” in reference to Arm’s customers is not intended to create or refer to any partnership relationship with any other company. Arm may make changes to this document at any time and without notice.

If any of the provisions contained in these terms conflict with any of the provisions of any click through or signed written agreement covering this document with Arm, then the click through or signed written agreement prevails over and supersedes the conflicting provisions of these terms. This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of the Agreement shall prevail.

The Arm corporate logo and words marked with ® or ™ are registered trademarks or trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners. Please follow Arm’s trademark usage guidelines at <http://www.arm.com/company/policies/trademarks>.

Copyright © 2017 Arm Limited (or its affiliates). All rights reserved.

Arm Limited. Company 02557590 registered in England.

110 Fulbourn Road, Cambridge, England CB1 9NJ.

LES-PRE-20349

**Confidentiality Status**

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by Arm and the party that Arm delivered this document to.

Unrestricted Access is an Arm internal classification.

**Product Status**

The information in this document is Final, that is for a developed product.

**Web Address**

<http://www.arm.com>

# Contents

## Cortex-M33 Cycle Model User Guide

### **Preface**

<i>About this book</i> .....	7
<i>Feedback</i> .....	9

### **Chapter 1**

#### **Introduction**

1.1	<i>Supported hardware features</i> .....	1-11
1.2	<i>Unsupported hardware features</i> .....	1-12
1.3	<i>Additional features for Cycle Model usability</i> .....	1-13

### **Chapter 2**

#### **Adding and configuring the SoC Designer component**

2.1	<i>SoC Designer component files</i> .....	2-15
2.2	<i>Adding the Cycle Model to the component library</i> .....	2-16

### **Chapter 3**

#### **Available component ports**

3.1	<i>Available ESL ports</i> .....	3-18
3.2	<i>Reset behavior and ports</i> .....	3-19
3.3	<i>Tied pins</i> .....	3-20

### **Chapter 4**

#### **Available component parameters**

4.1	<i>Changing parameter settings in SoC Designer</i> .....	4-22
4.2	<i>Component parameters</i> .....	4-23

### **Chapter 5**

#### **Debug features**

5.1	<i>Register information</i> .....	5-29
-----	-----------------------------------	------

5.2	<i>Disassembly view</i> .....	5-33
5.3	<i>Memory view</i> .....	5-34
5.4	<i>Hardware profiling</i> .....	5-35

# Preface

This preface introduces the *Cortex-M33 Cycle Model User Guide*.

It contains the following:

- [About this book](#) on page 7.
- [Feedback](#) on page 9.

## About this book

This document describes how to use the Cortex-M33 Cycle Model in SoC Designer.

### Product revision status

The *rmprn* identifier indicates the revision status of the product described in this book, for example, *r1p2*, where:

*rm* Identifies the major revision of the product, for example, *r1*.

*prn* Identifies the minor revision or modification status of the product, for example, *p2*.

### Intended audience

### Using this book

This book is organized into the following chapters:

#### Chapter 1 Introduction

This section summarizes the functionality of the Cycle Model compared to that of the hardware, and describes the performance and accuracy of the Cycle Model. For details, see the *Cortex-M33 Technical Reference Manual* (Arm 100230).

#### Chapter 2 Adding and configuring the SoC Designer component

This section provides basic information about using the Cycle Model component. See the *SoC Designer User Guide* (100996) for more information.

#### Chapter 3 Available component ports

This section describes the differences between the pins in the hardware and those on the Cycle Model.

#### Chapter 4 Available component parameters

This section describes the component parameters and how to set them.

#### Chapter 5 Debug features

This section describes the debug features supported by the Cycle Model CADI debug interface.

## Glossary

The Arm® Glossary is a list of terms used in Arm documentation, together with definitions for those terms. The Arm Glossary does not contain terms that are industry standard unless the Arm meaning differs from the generally accepted meaning.

See the *Arm® Glossary* for more information.

## Typographic conventions

*italic*

Introduces special terminology, denotes cross-references, and citations.

**bold**

Highlights interface elements, such as menu names. Denotes signal names. Also used for terms in descriptive lists, where appropriate.

`monospace`

Denotes text that you can enter at the keyboard, such as commands, file and program names, and source code.

monospace

Denotes a permitted abbreviation for a command or option. You can enter the underlined text instead of the full command or option name.

`monospace italic`

Denotes arguments to monospace text where the argument is to be replaced by a specific value.

### **monospace bold**

Denotes language keywords when used outside example code.

### **<and>**

Encloses replaceable terms for assembler syntax where they appear in code or code fragments.  
For example:

```
MRC p15, 0, <Rd>, <CRn>, <CRm>, <Opcode_2>
```


### **SMALL CAPITALS**

Used in body text for a few terms that have specific technical meanings, that are defined in the *Arm® Glossary*. For example, IMPLEMENTATION DEFINED, IMPLEMENTATION SPECIFIC, UNKNOWN, and UNPREDICTABLE.

## **Timing diagrams**

The following figure explains the components used in timing diagrams. Variations, when they occur, have clear labels. You must not assume any timing information that is not explicit in the diagrams.

Shaded bus and signal areas are undefined, so the bus or signal can assume any value within the shaded area at that time. The actual level is unimportant and does not affect normal operation.



**Figure 1 Key to timing diagram conventions**

## **Signals**

The signal conventions are:

### **Signal level**

The level of an asserted signal depends on whether the signal is active-HIGH or active-LOW.  
Asserted means:

- HIGH for active-HIGH signals.
- LOW for active-LOW signals.

### **Lowercase n**

At the start or end of a signal name denotes an active-LOW signal.

## **Additional reading**

### **Arm publications**

### **Other publications**



## Feedback

### Feedback on this product

If you have any comments or suggestions about this product, contact your supplier and give:

- The product name.
- The product revision or version.
- An explanation with as much information as you can provide. Include symptoms and diagnostic procedures if appropriate.

### Feedback on content

If you have comments on content then send an e-mail to [errata@arm.com](mailto:errata@arm.com). Give:

- The title *Cortex-M33 Cycle Model User Guide*.
- The number 101110\_0906\_00\_en.
- If applicable, the page number(s) to which your comments refer.
- A concise explanation of your comments.

Arm also welcomes general suggestions for additions and improvements.

————— **Note** —————

Arm tests the PDF only in Adobe Acrobat and Acrobat Reader, and cannot guarantee the quality of the represented document when used with any other PDF reader.

---

# Chapter 1

## Introduction

This section summarizes the functionality of the Cycle Model compared to that of the hardware, and describes the performance and accuracy of the Cycle Model. For details, see the *Cortex-M33 Technical Reference Manual* (Arm 100230).

It contains the following sections:

- [1.1 Supported hardware features on page 1-11.](#)
- [1.2 Unsupported hardware features on page 1-12.](#)
- [1.3 Additional features for Cycle Model usability on page 1-13.](#)

## 1.1 Supported hardware features

The following features of the Cortex-R52 hardware are fully implemented in the Cortex-R52 Cycle Model:

- Configurations of up to four CPUs are supported.
- Configurable number of interrupts (32 to 960 in increments of 32).
- AXI master port.
- Access to TCMs via slave port.
- Variable ICache and DCache sizes.
- Variable ITCM and DTCM sizes.
- 16, 20, or 24 EL1-controlled MPU regions per core configurable at build time.
- 0, 16, 20, or 24 EL2-controlled MPU regions per core configurable at build time.
- Floating Point Unit (FPU).
- ETM interface, including register slice between the processor and ETM interface.
- RAM protection.

## 1.2 Unsupported hardware features

The following features of the Cortex-R52 hardware are not implemented in the Cortex-R52 Cycle Model:

- Semihosting.
- Split-lock mode.
- Error Correcting Code (ECC) on RAM blocks and buses.
- Memory Built-In Self Test (MBIST) interface.
- Memory Reconstruction Port (MRP).
- Use of Synopsys® DesignWare® library blocks rather than the Arm equivalents.
- Configurable size for Branch Target Address Cache (BTAC).
- Addition of one latency cycle to ITCM data read.
- Support for additional signals to control power (required for UPF).

## 1.3 Additional features for Cycle Model usability

The following features that are implemented in the Cycle Model do not exist in the hardware. These features have been added to the Cycle Model for enhanced usability.

- Waveform dumping using the waveform-related parameters described in Table 1-3 on page 21.
- Support for viewing registers (see [Register information](#)).
- Support for viewing memory (see [Memory view](#)).
- Support for disassembly view (see [Disassembly view](#)).
- Support for hardware profiling (see [Hardware profiling](#)).

## Chapter 2

# Adding and configuring the SoC Designer component

This section provides basic information about using the Cycle Model component. See the *SoC Designer User Guide* (100996) for more information.

It contains the following sections:

- [2.1 SoC Designer component files](#) on page 2-15.
- [2.2 Adding the Cycle Model to the component library](#) on page 2-16.

## 2.1 SoC Designer component files

The component files are the final output from the Cycle Model Studio compile and are the input to SoC Designer.

There are two versions of the component: an optimized release version for normal operation, and a debug version.

On Linux, the debug version of the component is compiled without optimizations and includes debug symbols for use with gdb. The release version is compiled without debug information and is optimized for performance.

On Windows, the debug version of the component is compiled referencing the debug runtime libraries so it can be linked with the debug version of SoC Designer. The release version is compiled referencing the release runtime library. Both release and debug versions generate debug symbols for use with the Visual C++ debugger on Windows.

The component files provided with your Cycle Model are:

**Table 2-1 SoC Designer component files**

Platform	File	Description
Linux	maxlib.lib<component_name>.conf	SoC Designer configuration file
	lib.<component_name>.mx.so	SoC Designer component runtime file
	lib<component_name>.mx_DBG.so	SoC Designer component debug file
Windows	maxlib<component_name>.lib.windows.conf	SoC Designer configuration file
	lib<component_name>.mx.dll	SoC Designer component runtime file
	lib<component_name>.mx_DBG.dll	SoC Designer component debug file

Additionally, this User Guide PDF is provided with the component.

## 2.2 Adding the Cycle Model to the component library

The compiled Cycle Model component is provided as a configuration file (.conf).

To make the component available in the Component Window in SoC Designer Canvas:

### Procedure

1. Launch SoC Designer Canvas.
2. Select **File > Preferences**.
3. In the list on the left, click **Component Library**.
4. Under the **Additional Component Configuration Files** window, click **Add**.
5. Browse to the location where the Cycle Model is located and select the component configuration (.conf) file.
6. Click **OK**.
7. To save the preferences permanently, click the **OK & Save** button. The component is now available from the SoC Designer Component Window.
8. To pull the component onto the canvas, select and drag it.

The component's appearance may vary depending on your specific device configuration. Additional ports are provided depending on the model RTL configuration file (default.conf) used to create the Cycle Model.



## Chapter 3

# Available component ports

This section describes the differences between the pins in the hardware and those on the Cycle Model.

It contains the following sections:

- [3.1 Available ESL ports on page 3-18.](#)
- [3.2 Reset behavior and ports on page 3-19.](#)
- [3.3 Tied pins on page 3-20.](#)

## 3.1 Available ESL ports

Table 1-2 describes the ESL ports that are exposed in SoC Designer. See the *Cortex-R52 Technical Reference Manual* for more information.

**Table 3-1 SoC Designer component files**

ESL Port	Description	Type
ACP_Slave_AXISlave	ACP Slave debug port (AXI)	Transaction Slave
APB_Slave_Debug_APB	APB Slave debug port	Transaction Slave
AXI4_Master_LLPP_AXI_x	AXI4 Master Low Latency Peripheral port	Transaction Master
AXI4_Master_Main_AXI_x	AXI4 Master Main port	Transaction Master
AXI4_RO_Flash_Master_x	CPU Flash Interface	Transaction Master
CLKIN	Main clock of the Cortex-R52 MPCore processor.	Main Clock Transactor (Clock Slave)
clk-in	This port is used internally. Leave unconnected.	Clock Slave

## 3.2 Reset behavior and ports

The Cycle Model is reset internally each time SoC Designer Simulator is initialized. This behavior is standard and can not be changed. To view the internal reset sequence, set the **Align Waveforms** parameter to False, and this data appears in the waveform.

At simulation time zero and while simulation is running, you can generate a reset sequence. To do so, drive the reset pins on the component using external signals (for example, using the MxSigDriver component).

For information about reset pin names, bit ordering (for multiple cores), and required reset sequence, refer to the Technical Reference Manual for your IP.

### 3.3 Tied pins

The following signals are tied to a certain value:

- DFTCGEN (low)
- DFTRAMHOLD (low)
- DFTRSTDISABLE (low)
- DFTMCPHOLD (low)
- MBISTADDREXT (17 bits, all tied low)
- MBISTARRAYEXT (5 bits, all tied low)
- MBISTCFGEXT (low)
- MBISTINDATAEXT (78 bits, all tied low)
- MBISTREADENEXT (low)
- MBISTWRITEENEXT (low)
- MBISTREQEXT (high)
- 0NIDEN0 (high)
- NIDEN0 (high)
- DBGEN0 (high)
- HIDEN0 (high)
- HNIDEN0 (high)
- ACLKENF0 (high)
- ACLKENM0 (high)
- ACLKENP0 (high)
- PCLKENDBG (high)
- ACLKENS (high)
- CNTCLKEN (high)

# Chapter 4

## **Available component parameters**

This section describes the component parameters and how to set them.

It contains the following sections:

- [4.1 Changing parameter settings in SoC Designer on page 4-22.](#)
- [4.2 Component parameters on page 4-23.](#)

## 4.1 Changing parameter settings in SoC Designer

You can change the settings of all the component parameters in SoC Designer Canvas, and of some of the parameters in SoC Designer Simulator.

To modify the component parameters:

1. In SoC Designer Canvas, right-click on the component and select **Component Information**. You can also double-click the component. The **Edit Parameters** dialog box appears. The list of available parameters may differ slightly depending on the settings that you enabled in the configuration file (`default.conf`) when creating the component.
2. In the **Parameters** window, double-click the **Value** field of the parameter that you want to modify.
3. For text fields, type a new value. If a pulldown menu is available, select the desired value.

## 4.2 Component parameters

The following table describes the Cycle Model component parameters. Complete details about the parameters in this table are available in the Integration and Implementation Manual or Technical Reference Manual for your IP.

**Table 4-1 Component parameters**

Parameter name	Description	Allowed values	Default value	Init/ Runtime
ACLKENF <sub>m</sub>	Flash port clock enable.	0, 1	1	Runtime
ACLKENM <sub>m</sub>	AXI master port clock enable.	0, 1	1	Runtime
ACLKENP <sub>m</sub>	Low Latency Peripheral Port (LLPP) clock enable.	0, 1	1	Runtime
ACLKENS	AXI slave port clock enable.	0, 1	0	Runtime
ACP_Slave_AXISlave axi_size[0-5]	This parameter should be left at its default value.	—	0	Init
ACP_Slave_AXISlave axi_start[0-5]	This parameter should be left at its default value.	—	0	Init
ACP_Slave_AXISlave Enable Debug Messages	Whether debug messages are enabled on the AXI Slave port.	true, false	false	Runtime
ACP_Slave_AXISlave Protocol Variant	Protocol Variant in use for AXI.	AXI4	AXI4	Init
AFVALIDD <sub>m</sub>	FIFO flush request (ATB Data).	0, 1	0	Runtime
AFVALIDI <sub>m</sub>	FIFO flush request (ATB Instruction).	0, 1	0	Runtime
Align Waveforms	When set to true, waveforms dumped by the component are aligned with the SoC Designer simulation time. The reset sequence, however, is not included in the dumped data. When set to false, the reset sequence is dumped to the waveform data, however, the component time is not aligned with SoC Designer time.	true, false	true	Init
APB_Slave_Debug_APB Base Address	APB Slave debug base address.	Integer	0	Init
APB_Slave_Debug_APB Enable Debug Messages	Whether debug messages are enabled on the APB Slave port.	true, false	false	Runtime
APB_Slave_Debug_APB Protocol Variant	Protocol Variant in use for APB.	APB3	APB3	Init
APB_Slave_Debug_APB Size	APB Slave debug size.	Integer	0	Init
ATCLKEND	Clock enable for the ATB interfaces.	0, 1	0	Runtime
ATCLKENI	ATB clock enable and clock enable for TSVALUEB[63:0].	0, 1	0	Runtime

**Table 4-1 Component parameters (continued)**

Parameter name	Description	Allowed values	Default value	Init/ Runtime
ATCMSIZE $m$	Sets ATCM Size.	0 KB, 8 KB, 16 KB, 32 KB, 64 KB, 128 KB, 256 KB, 512 KB, 1 MB	32 KB	Init
ATCM_WAIT_STATES $m$	Sets ATCM wait state.	0, 1	0	Init
ATREADYD $m$	ATB device ready (ATB Data).	0, 1	0	Runtime
ATREADYI $m$	ATB device ready (ATB Instruction).	0, 1	0	Runtime
AXI4_Master_LLPP_AXI_ $m$ Enable Debug Messages	Enables AXI4 Master LLPP port debug.	true, false	false	Runtime
AXI4_Master_LLPP_AXI_ $m$ Protocol Variant	Specifies variant in use on AXI4 Master LLPP port.	AXI4	AXI4	Init
AXI4_Master_Main_AXI_ $m$ Enable Debug Messages	Enables AXI4 Master Main port debug.	true, false	false	Runtime
AXI4_Master_Main_AXI_ $m$ Protocol Variant	Specifies variant in use on AXI4 Main port.	AXI4	AXI4	Init
AXI4_RO_Flash_Master_0 Enable Debug Messages	Enables AXI4 RO Flash Master port debug.	true, false	false	Runtime
AXI4_RO_Flash_Master_0 Protocol Variant	Specifies variant in use on AXI4 RO Flash Master port.	AXI4	AXI4	Init
BTCMSIZE $m$	Sets BTCM size.	0 KB, 8 KB, 16 KB, 32 KB, 64 KB, 128 KB, 256 KB, 512 KB, 1 MB	32 KB	Init
BTCM_WAIT_STATES $m$	Sets BTCM wait state.	0, 1	0	Init
ARM_CM DB Path	Sets the directory path to the database file.	not used	empty	Init
CFGAXISTCMBASEADDR	Base address of the TCMs on the AXI-slave interface.	Integer	0x1000000	Init
CFGCLUSTERUTID	Cluster Unique Transaction IDentifier for the purpose of interconnect protection.	0 - 3	0	Init
CFGDBGROMADDR	Debug ROM table address.	Integer	0x12000	Init
CFGDMBROMADDRV	Debug ROM table address enable.	true, false	false	Init
CFGENDIANESS $m$	Data endianness.	0, 1	0	Init
CFGFLASHBASEADDR	Base address of the flash interface.	Integer	0x8000000	Init
CFGFLASHEN $m$	Flash interface enabled or disabled out of reset.	0, 1	1	Init
CFGFLASHIMP	Flash region present in memory map.	0, 1	1	Init



**Table 4-1 Component parameters (continued)**

Parameter name	Description	Allowed values	Default value	Init/ Runtime
CFGFLASHPROTEN	Flash memory protection enable out of reset.	true, false	false	Init
CFGFLASHPROTIMP	Flash memory protection support.	0, 1	0	Init
CFGINITREG	Program-visible registers initialized to known value out of reset.	0, 1	0	Init
CFGGL1CACHEINVDIS <sub>m</sub>	Automatic post-reset L1 cache invalidate disable.	0, 1	1	Init
CFGLLPPBASEADDR	Base address of the LLPP.	Integer1	0xB0000	Init
CFGLLPPIMP	LLPP region present in memory map.	0, 1	1	Init
CFGLLPPSIZE	Region size of the LLPP. See the Cortex-R52 TRM for more information.	4 bits	0xD	Init
CFGMPIDRAFF1	Cluster ID at affinity level 1.	8 bits	0	Init
CFGMPIDRAFF2	Cluster ID at affinity level 2.	8 bits	0	Init
CFGMRPEN	MRP enable.	0, 1	0	Runtime
CFGPERIPBASE	Base address of the memory-mapped registers, which is principally the interrupt distributor control.	Integer1	0xE1E00000	Init
CFGGRAMPROTEN	RAM (caches and TCMs) memory protection enable out of reset.	true, false	false	Init
CFGTCMBOOT <sub>m</sub>	ATCM enabled and at address 0x0 out of reset.	0, 1	0	Init
CFGTHUMBEXCEPTIONS <sub>m</sub>	Instruction set state (A32 or T32) and value of HSCTLR.TE out of reset.	0, 1	0	Init
CFGVECTABLE <sub>m</sub>	Vector table base address out of reset.	Integer1	0x20	Init
CLREXMONREQ	Clearing of the external global exclusive monitor request. When asserted, this signal acts as a WFE wake-up event to all cores.	0, 1	0	Runtime
CNTVALUEB	Global system counter value in binary format.	Integer1	0	Runtime
COREPREQ <sub>m</sub>	P-channel request.	0, 1	0	Runtime
COREPSTATE <sub>m</sub>	P-channel state.	0, 1	0	Runtime
CPUHALT <sub>m</sub>	Core waits out of reset before going through reset sequence. Reset to false to fetch instructions.	true, false	false	Runtime
CTCMSIZE <sub>m</sub>	Sets CTCM size.	0 KB, 8 KB, 16 KB, 32 KB, 64 KB, 128 KB, 256 KB, 512 KB, 1 MB	32 KB	Init

**Table 4-1 Component parameters (continued)**

Parameter name	Description	Allowed values	Default value	Init/ Runtime
CTCM_WAIT_STATES <sub>m</sub>	Sets CTCM wait state.	0, 1	0	Init
CTMCHIN	CTM input channel interface.	Integer1	0	Runtime
CTMCHOUTACK	CTM input channel interface acknowledge.	Integer1	0	Runtime
CTMCIHSBYPASS	CTM channel interfaces handshake bypass for each channel.	Integer1	0	Runtime
CTMCISBYPASS	CTM channel interfaces synchronization bypass. Same for all channels.	0, 1	0	Runtime
DCACHESIZE <sub>m</sub>	Sets data cache size.	4 KB, 8 KB, 16 KB, 32 KB	32 KB	Init
Dump Waveforms	Whether SoC Designer dumps waveforms for this component.	true, false	false	Runtime
EDBGRQ <sub>m</sub>	Individual processor external debug request.	0 - f	0	Init
Enable Debug Messages	Whether debug messages are enabled for the component.	true, false	false	Runtime
EVENTI	Event input for processor wake-up from WFE low-power state.	0, 1	0	Runtime
EXTPPI <sub>m</sub>	External private peripheral interrupts into the GDU.	Integer1	0	Runtime
ICACHESIZE <sub>m</sub>	Sets Instruction Cache Size.	4 KB, 8 KB, 16 KB, 32 KB	32 KB	Init
LATEERRF <sub>m</sub>	Late data error. See the Cortex-R52 TRM for details.	0, 1	0	Runtime
MRPBACKPRESS <sub>m</sub>	Driven by the slave connected to the MRP. See the Cortex-R52 TRM for details.	0, 1	0	Runtime
PADDRDBG	APB address bus bits[22:2].	Integer1	0	Runtime
PCLKENDBG	APB clock enable.	0, 1	1	Runtime
RAM_PROT <sub>m</sub>	RAM protection supported.	0, 1	1	Init
RDATACODEF <sub>m</sub>	Read data.	Integer1	0	Runtime
SEI <sub>m</sub>	Physical system error interrupt into the core. Active HIGH, edge-sensitive.	0, 1	0	Runtime
SPI	Shared peripheral interrupts into the GDU.	Integer1	0	Runtime
SYNCREQD <sub>m</sub>	Synchronization request from data trace sink.	0, 1	0	Runtime
SYNCREQI <sub>m</sub>	Synchronization request from instruction trace sink.	0, 1	0	Runtime

**Table 4-1 Component parameters (continued)**

Parameter name	Description	Allowed values	Default value	Init/ Runtime
TSVALUEB	Timestamp value.	Integer1	0	Runtime
VSEIm	Virtual system error interrupt into the core.	0, 1	0	Runtime
Waveform File	Name of the waveform file. When enabled, SoC Designer writes accumulated waveforms to the waveform file in the following situations: when the waveform buffer fills, when validation is paused and when validation finishes, and at the end of each validation run.	string	arm_cm_Cortex-R52.vcd	Init
Waveform Format	Format of the waveform dump file.	VCD	VCD	Init
Waveform Timescale	Sets the timescale to be used in the waveform.	1 ns	1 ns	Init

# Chapter 5

## Debug features

This section describes the debug features supported by the Cycle Model CADI debug interface.

It contains the following sections:

- [5.1 Register information on page 5-29.](#)
- [5.2 Disassembly view on page 5-33.](#)
- [5.3 Memory view on page 5-34.](#)
- [5.4 Hardware profiling on page 5-35.](#)

## 5.1 Register information

This section describes the supported register views.

### AArch32\_Core Registers

**Table 5-1 AArch32\_Core Registers**

Name	Access
R0	Read-Write
R1	Read-Write
R2	Read-Write
R3	Read-Write
R4	Read-Write
R5	Read-Write
R6	Read-Write
R7	Read-Write
R8_usr	Read-Write
R9_usr	Read-Write
R10_usr	Read-Write
R11_usr	Read-Write
R12_usr	Read-Write
R15	Read-Only
R13_usr	Read-Write
R14_usr	Read-Write
R13_svc	Read-Write
R14_svc	Read-Write
R13_irq	Read-Write
R14_irq	Read-Write
R8_fiq	Read-Write
R9_fiq	Read-Write
R10_fiq	Read-Write
R11_fiq	Read-Write
R12_fiq	Read-Write
R8	Read-Write
R9	Read-Write
R10	Read-Write
R11	Read-Write
R12	Read-Write
R13_fiq	Read-Write

**Table 5-1 AArch32\_Core Registers (continued)**

<b>Name</b>	<b>Access</b>
R14_fiq	Read-Write
R13_und	Read-Write
R14_und	Read-Write
R13_abt	Read-Write
R14_abt	Read-Write
R13_hyp	Read-Write
ELR_hyp	Read-Write
R13	Read-Write
R14	Read-Write
CPSR_nodbg	Read-Write
DSPSR_dbg	Read-Write
CPSR	Read-Write
SPSR_svc	Read-Write
SPSR_irq	Read-Write
SPSR_fiq	Read-Write
SPSR_und	Read-Write
SPSR_abt	Read-Write
SPSR_hyp	Read-Write
SPSR	Read-Write
ExtendedTargetFeatures	Read-Only
PC_MEMSPACE	Read-Write

## Aarch32 ID Registers

**Table 5-2 Aarch32 ID Registers**

<b>Name</b>	<b>Access</b>
MIDR	Read-Only
CTR	Read-Only
TCMTR	Read-Only
TLBTR	Read-Only
MPIDR	Read-Only
MPUIR	Read-Only
REVIDR	Read-Only
ID_PFR0	Read-Only
ID_PFR1	Read-Only
ID_DFR0	Read-Only

**Table 5-2 Aarch32 ID Registers (continued)**

<b>Name</b>	<b>Access</b>
ID_AFR0	Read-Only
ID_MMFR0	Read-Only
ID_MMFR1	Read-Only
ID_MMFR2	Read-Only
ID_MMFR3	Read-Only
ID_MMFR4	Read-Only
ID_ISAR0	Read-Only
ID_ISAR1	Read-Only
ID_ISAR2	Read-Only
ID_ISAR3	Read-Only
ID_ISAR4	Read-Only
ID_ISAR5	Read-Only
CCSIDR	Read-Only
CLIDR	Read-Only
AIDR	Read-Only

## AArch32 Control Registers

**Table 5-3 AArch32 Control Registers**

<b>Name</b>	<b>Access</b>
SCTLR	Read-Write
ACTLR	Read-Only
ACTLR2	Read-Only
DFSR	Read-Write
IFSR	Read-Write

## AArch32 PERF Registers

**Table 5-4 AArch32 PERF Registers**

<b>Name</b>	<b>Access</b>
PMCR	Read-Write
PMCNTENSET	Read-Write
PMCNTENCLR	Read-Write
PMOVSr	Read-Write
PMSELR	Read-Write
PMCEID0	Read-Only
PMCEID1	Read-Only

**Table 5-4 AArch32 PERF Registers (continued)**

<b>Name</b>	<b>Access</b>
PMCCNTR	Read-Write
PMXEVTYPER	Read-Write
PMXVCNTR	Read-Write
PMUSERENR	Read-Write
PMINTENSET	Read-Write
PMINTENCLR	Read-Write
PMEVCNTR0	Read-Write
PMEVTYPER0	Read-Write
PMEVCNTR1	Read-Write
PMEVTYPER1	Read-Write
PMEVCNTR2	Read-Write
PMEVTYPER2	Read-Write
PMEVCNTR3	Read-Write
PMEVTYPER3	Read-Write
PMCCFILTR	Read-Write
PMOVSSET	Read-Write



## 5.2 Disassembly view

SoC Designer Simulator supports a disassembly view of a program running on the Cycle Model.

To display the disassembly view in SoC Designer Simulator, right-click on the Cycle Model and select **View Disassembly...** from the context menu. Refer to the *SoC Designer User Guide* (100996) for more information.

All CADI windows support breakpoints. When double-clicking on the proper location a red dot indicates that a breakpoint is currently active. To remove the breakpoints simply doubleclick on the same location again.

## 5.3 Memory view

SoC Designer Simulator supports a memory view of a program running on the Cycle Model.

The Memory view does not include TCM and Cache.

To display the memory view in SoC Designer Simulator, right-click on the Cycle Model and select **View Child Memory for...** from the context menu. Refer to the *SoC Designer User Guide* (100996) for more information.

This is not a coherent view; cache is not taken into account.

## 5.4 Hardware profiling

Profiling data is enabled, and can be viewed using the Profiling Manager, which is accessible via the **Debug** menu in the SoC Designer Simulator. Software profiling is not supported.

The Cycle Model supports the full set of hardware profiling events. See the *Cortex-R52 Processor Technical Reference Manual* (100026) for the list of supported profiling events.