



# Release Note for Arm GNU Toolchain

13.3.Rel1

**Non-Confidential**

Copyright © 2022–2024 Arm Limited (or its affiliates).  
All rights reserved.

**Issue**

109845\_13.3.Rel1\_en



## Release Note for Arm GNU Toolchain

Copyright © 2022–2024 Arm Limited (or its affiliates). All rights reserved.

### Release information

#### Document history

Issue	Date	Confidentiality	Change
13.3.Rel1	4 July 2024	Non-Confidential	13.3.Rel1 Release
13.2.Rel1	30 October 2023	Non-Confidential	13.2.Rel1 Release
12.3.Rel1	28 July 2023	Non-Confidential	12.3.Rel1 Release
12.2.MPACBTI-Rel1	22 March 2023	Non-Confidential	12.2.MPACBTI-Rel1 Release
12.2.Rel1	22 December 2022	Non-Confidential	12.2.Rel1 Release
12.2.MPACBTI-Bet1	6 September 2022	Non-Confidential	12.2.MPACBTI-Bet1 Release
11.3.Rel1	8 August 2022	Non-Confidential	11.3.Rel1 Release
11.2-2022.02	15 February 2022	Non-Confidential	11.2-2022.02 Release

### Proprietary Notice

This document is protected by copyright and other related rights and the use or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of Arm Limited ("Arm"). No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether the subject matter of this document infringes any third party patents.

The content of this document is informational only. Any solutions presented herein are subject to changing conditions, information, scope, and data. This document was produced using reasonable efforts based on information available as of the date of issue of this document. The scope of information in this document may exceed that which Arm is required to provide, and such additional information is merely intended to further assist the recipient and does not represent Arm's view of the scope of its obligations. You acknowledge and agree that you possess the necessary expertise in system security and functional safety and that you shall be solely

responsible for compliance with all legal, regulatory, safety and security related requirements concerning your products, notwithstanding any information or support that may be provided by Arm herein. In addition, you are responsible for any applications which are used in conjunction with any Arm technology described in this document, and to minimize risks, adequate design and operating safeguards should be provided for by you.

This document may include technical inaccuracies or typographical errors. THIS DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, Arm makes no representation with respect to, and has undertaken no analysis to identify or understand the scope and content of, any patents, copyrights, trade secrets, trademarks, or other rights.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Reference by Arm to any third party's products or services within this document is not an express or implied approval or endorsement of the use thereof.

This document consists solely of commercial items. You shall be responsible for ensuring that any permitted use, duplication, or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word "partner" in reference to Arm's customers is not intended to create or refer to any partnership relationship with any other company. Arm may make changes to this document at any time and without notice.

This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of this document shall prevail.

The validity, construction and performance of this notice shall be governed by English Law.

The Arm corporate logo and words marked with ® or ™ are registered trademarks or trademarks of Arm Limited (or its affiliates) in the US and/or elsewhere. Please follow Arm's trademark usage guidelines at <https://www.arm.com/company/policies/trademarks>. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners.

Arm Limited. Company 02557590 registered in England.

110 Fulbourn Road, Cambridge, England CB1 9NJ.

PRE-1121-V1.0

## Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by Arm and the party that Arm delivered this document to.

Unrestricted Access is an Arm internal classification.

## Product Status

The information in this document is Final, that is for a developed product.

## Feedback

Arm welcomes feedback on this product and its documentation. To provide feedback on the product, create a ticket on <https://support.developer.arm.com>

To provide feedback on the document, fill the following survey: <https://developer.arm.com/documentation-feedback-survey>.

## Inclusive language commitment

Arm values inclusive communities. Arm recognizes that we and our industry have used language that can be offensive. Arm strives to lead the industry and create change.

We believe that this document contains no offensive language. To report offensive language in this document, email [terms@arm.com](mailto:terms@arm.com).

# Contents

1. Release Note for Arm GNU Toolchain 13.2.Rel1.....	6
--	---

# 1. Release Note for Arm GNU Toolchain 13.2.Rel1

This is release 13.3.Rel1 of Arm GNU Toolchain.

Arm GNU Toolchain releases package pre-built binaries of GNU Toolchain for various Arm targets. These are community supported and come with no warranty. For more information, please visit the [arm Developer page](#).

This release includes bare-metal and Linux toolchains for various hosts, as described in the Host Support section.

## Changes since Arm GNU Toolchain 13.2.Rel1

Changes since Arm GNU Toolchain 13.2.Rel1:

- Updated GCC to source code based on version 13.3.
- Updated Binutils to source code based on version 2.42.
- Updated GDB version 14.
- Updated Newlib source code to a version on trunk.

## Known Limitations, Issues and Updates

Known limitations, issues and updates:

- In this release, the Windows and macOS hosted toolchains provide GDB without Python support. The Linux hosted toolchains provide a GDB executable with Python support, and another GDB executable without Python support. The filename of the GDB executable that has the Python support, has the suffix `-py`. The GDB executable without the `-py` suffix does not have Python support. Previous releases of the Linux hosted toolchains provided only one GDB executable, without the suffix `-py`, and that had python support. See Installation Instructions for information on installing Python, to use GDB with Python support.
- When you decompress the windows packages, the decompression requests permission to overwrite certain files. This is because the files have similar names with different case, which are treated as identical names on a Windows host. You can choose to overwrite the files with identical names.
- Doing IPA on CMSE generates a linker error: The linker will error out when resulting object file contains a symbol for the clone function with the `__acle_se` prefix that has a non-local binding. Issue occurs when compiling binaries for M-profile Secure Extensions where the compiler may decide to clone a function with the `cmse_nonsecure_entry` attribute. Although cloning nonsecure entry functions is legal, as long as the clone is only used inside the secure application, the clone function itself should not be seen as a secure entry point and so it should not have the `__acle_se` prefix. A possible workaround for this is to add a 'noclone' attribute to functions with the 'cmse\_nonsecure\_entry'. This will prevent GCC from cloning such functions.
- GCC can hang or crash if the input source code uses MVE Intrinsics polymorphic variants in a nested form. The depth of nesting that triggers this issue might vary depending on the host machine. This behaviour is observed when nesting 7 times or more on a high-end workstation.

On less powerful machines, this behaviour might be observed with fewer levels of nesting. This issue is reported in [https://gcc.gnu.org/bugzilla/show\\_bug.cgi?id=91937](https://gcc.gnu.org/bugzilla/show_bug.cgi?id=91937)

- GLIBC 2.39 has dropped support for the libcrypt library. Therefore, the libcrypt library might not be available from a future release of the Arm GNU Toolchain that uses GLIBC 2.39 or later. Users who require libcrypt support are encouraged to look into alternative sources such as libxcrypt.
- Support for CentOS Linux 7 and Ubuntu 18.04 is deprecated.
- The security issue described in [CVE-2024-0151](#) has been fixed. For more information, see the [Cortex-M Security Extensions \(CMSE\) Security Bulletin](#).

## Ask Questions

For any questions, please use the [Arm Community forums](#)

## Report Bugs

Please report any bugs via the [Linaro Bugzilla](#) under “GNU Binary Toolchain” product.

## Host Support

Host	Host Identifier (package name)	Toolchain Target
Windows on IA-32 or x86_64  Windows 10 or later	mingw-w64-i686	AArch64 Bare-metal  AArch64 Linux  AArch32 Bare-metal  AArch32 Linux hard-float
Linux on AArch64  These toolchains are built on and for Ubuntu 18.04 on AArch64, and will likely also be useable on OS versions: <ul style="list-style-type: none"> <li>• later than Ubuntu 18.04</li> <li>• RHEL8</li> </ul>	aarch64	AArch64 Bare-metal  AArch32 Bare-metal  AArch32 Linux hard-float
Linux on x86_64  These toolchains are built on CentOS7 on x86_64, and will likely also be useable on OS versions: <ul style="list-style-type: none"> <li>• RHEL7 and RHE8</li> <li>• Ubuntu 18.04 or later</li> </ul>	x86_64	AArch64 Bare-metal  AArch64 Linux  AArch64 Linux big-endian  AArch32 Bare-metal  AArch32 Linux hard-float
macOS on x86_64  macOS 12 or later	darwin-x86_64	AArch64 Bare-metal  AArch32 Bare-metal

Host	Host Identifier (package name)	Toolchain Target
macOS on Apple silicon	darwin-arm64	AArch64 Bare-metal
macOS 11 or later		AArch32 Bare-metal

## Included Toolchains

The packages of the released GNU toolchain binaries have the following naming convention:

```
arm-gnu-toolchain-<Release Version>-<Host>-<Target Triple>.tar.xz
```

- In the following table, <Target Triple> is listed in parentheses in the second column as part of target description.
- The format of <Release Version> is:  
  

```
<GCC Major Version>.<GCC Minor Version>.[<Feature>-]{Alp|Bet|Rel}<Revision>
```
- For Windows, the binaries are provided in zip files and with installers.
- For Linux, the binaries are provided as tarball files.
- For macOS, the binaries are provided as tarball files and pkg files.

Toolchain Package Name	Host OS / Target Description
arm-gnu-toolchain-13.3.rel1-aarch64-aarch64-none-elf.tar.xz	Host: Linux on AArch64  Target: AArch64 bare-metal (aarch64-none-elf)
arm-gnu-toolchain-13.3.rel1-aarch64-arm-none-eabi.tar.xz	Host: Linux on AArch64  Target: Arch32 bare-metal (arm-none-eabi)
arm-gnu-toolchain-13.3.rel1-aarch64-arm-none-linux-gnueabi.tar.xz	Host: Linux on AArch64  Target: AArch32 GNU/Linux target with hard float. (arm-none-linux-gnueabi)
arm-gnu-toolchain-13.3.rel1-mingw-w64-i686-arm-none-eabi.zip	Host: Windows  Target: AArch32 bare-metal (arm-none-eabi)
arm-gnu-toolchain-13.3.rel1-mingw-w64-i686-arm-none-eabi.exe	Host: Windows  Target: AArch32 bare-metal (arm-none-eabi)



Toolchain Package Name	Host OS / Target Description
arm-gnu-toolchain-13.3.rel1-mingw-w64-i686-aarch64-none-elf.zip	Host: Windows  Target: AArch64 bare-metal  (aarch64-none-elf)
arm-gnu-toolchain-13.3.rel1-mingw-w64-i686-aarch64-none-elf.exe	Host: Windows  Target: AArch64 bare-metal  (aarch64-none-elf)
arm-gnu-toolchain-13.3.rel1-mingw-w64-i686-arm-none-linux-gnueabi.zip	Host: Windows  Target: AArch32 GNU/Linux with hard float  (arm-none-linux-gnueabi)
arm-gnu-toolchain-13.3.rel1-mingw-w64-i686-arm-none-linux-gnueabi.exe	Host: Windows  Target: AArch32 GNU/Linux with hard float  (arm-none-linux-gnueabi)
arm-gnu-toolchain-13.3.rel1-mingw-w64-i686-aarch64-none-linux-gnu.zip	Host: Windows  Target: AArch64 GNU/Linux  (aarch64-none-linux-gnu)
arm-gnu-toolchain-13.3.rel1-mingw-w64-i686-aarch64-none-linux-gnu.	Host: Windows  Target: AArch64 GNU/Linux  (aarch64-none-linux-gnu)
arm-gnu-toolchain-13.3.rel1-x86_64-aarch64-none-elf.tar.xz	Host: Linux on x86_64  Target: AArch64 bare-metal  triple: aarch64-none-elf
arm-gnu-toolchain-13.3.rel1-x86_64-aarch64-none-linux-gnu.tar.xz	Host: Linux on x86_64  Target: AArch64 GNU/Linux  (aarch64-none-linux-gnu)
arm-gnu-toolchain-13.3.rel1-x86_64-aarch64_be-none-linux-gnu.tar.xz	Host: Linux on x86_64  Target: AArch64 GNU/Linux big-endian  (aarch64_be-none-linux-gnu)
arm-gnu-toolchain-13.3.rel1-x86_64-arm-none-eabi.tar.	Host: Linux on x86_64  Target: AArch32 bare-metal  (arm-none-eabi)

Toolchain Package Name	Host OS / Target Description
arm-gnu-toolchain-13.3.rel1-x86_64-arm-none-linux-gnueabi.tar.xz	Host: Linux on x86_64  Target: AArch32 GNU/Linux with hard float  (arm-none-linux-gnueabi)
arm-gnu-toolchain-13.3.rel1-darwin-x86_64-aarch64-none-elf.tar.xz	Host: macOS on x86_64  Target: AArch64 bare-metal  triple: aarch64-none-elf  (aarch64-none-elf)
arm-gnu-toolchain-13.3.rel1-darwin-x86_64-aarch64-none-elf.pkg	Host: macOS on x86_64  Target: AArch64 bare-metal  triple: aarch64-none-elf  (aarch64-none-elf)
arm-gnu-toolchain-13.3.rel1-darwin-x86_64-arm-none-eabi.tar.xz	Host: macOS on x86_64  Target: AArch32 bare-metal  (arm-none-eabi)
arm-gnu-toolchain-13.3.rel1-darwin-x86_64-arm-none-eabi.pkg	Host: macOS on x86_64  Target: AArch32 bare-metal  (arm-none-eabi)
arm-gnu-toolchain-13.3.rel1-darwin-arm64-aarch64-none-elf.tar.xz	Host: macOS on Apple silicon  Target: AArch64 bare-metal  triple: aarch64-none-elf  (aarch64-none-elf)
arm-gnu-toolchain-13.3.rel1-darwin-arm64-aarch64-none-elf.pkg	Host: macOS on Apple silicon  Target: AArch64 bare-metal  triple: aarch64-none-elf  (aarch64-none-elf)
arm-gnu-toolchain-13.3.rel1-darwin-arm64-arm-none-eabi.tar.xz	Host: macOS on Apple silicon  Target: AArch32 bare-metal  (arm-none-eabi)

Toolchain Package Name	Host OS / Target Description
arm-gnu-toolchain-13.3.rel1-darwin-arm64-arm-none-eabi.pkg	Host: macOS on Apple silicon  Target: AArch32 bare-metal  (arm-none-eabi)

## Released Files

Released files:

File Name	Description
arm-gnu-toolchain-*.tar.xz	Toolchain binaries
arm-gnu-toolchain-*.zip	Zipped toolchain binaries for Windows
arm-gnu-toolchain-*.exe	Toolchain installer for Windows
arm-gnu-toolchain-*.pkg	Toolchain installer for macOS
arm-gnu-toolchain--src-snapshot-.tar.xz	Toolchain sources
arm-gnu-toolchain-*--src-manifest.txt	List of remote repositories and the revisions of the source code used for building the toolchain
arm-gnu-toolchain-*--abe-manifest.txt	Input files for the Linaro ABE build system.
*.asc	MD5 checksum files for sources and binaries
*.sha256asc	SHA256 checksum files for sources and binaries

## Source Code

The sources for this release are provided in the source tar ball, arm-gnu-toolchain-src-snapshot-12.2.rel1.tar.xz, and includes the following items:

Project	Version	Repository/Branch/Revision
GCC	based on 13.3	git://gcc.gnu.org/git/gcc.git  branch: releases/gcc-13  revision: 7da2f895bd3294cc3f6bd202c73bce78d71c73bf  For information on vendor branches, see <a href="https://gcc.gnu.org/gitwrite.html#vendor">https://gcc.gnu.org/gitwrite.html#vendor</a>
glibc	2.38	git://sourceware.org/git/glibc.git  branch: release/2.38/master  revision: c8cb4d2b86ece572793e31a3422ea29e88d77df5
newlib		git://sourceware.org/git/newlib-cygwin.git
newlib-nano		revision: 1ed15161362b2eb5649b049b7ab0aaf8097bd43a
binutils	based on 2.42	git://sourceware.org/git/binutils-gdb.git  branch: binutils-2_42-branch  revision: e830307135a1cb6410613641a893a3cd9e6bd6b0

Project	Version	Repository/Branch/Revision
GDB	based on 14	git://sourceware.org/git/binutils-gdb.git  branch: gdb-14-branch  revision: b74fd1875e2d5381a61a4c8b67684ce5a45bbd62
libexpat	based on 2.2.5	Sources are provided in release source tar ball
Linux Kernel		git://git.kernel.org/pub/scm/linux/kernel/git/stable/linux-stable.git  revision: v4.20.13
libgmp	based on 6.2	Sources are provided in release source tar ball
libisl	based on 0.15	Sources are provided in release source tar ball
libmpfr	based on 3.1.6	Sources are provided in release source tar ball
libmpc	based on 1.0.3	Sources are provided in release source tar ball
libiconv	based on 1.15	Sources are provided in release source tar ball

## Installation Instructions

Verifying the downloaded packages

You may check using MD5 checksum as follows:

```
$ md5sum --check arm-gnu-toolchain-13.3.rel1-x86_64-aarch64-none-linux-
gnu.tar.xz.asc
arm-gnu-toolchain-13.3.rel1-x86_64-aarch64-none-linux-gnu.tar.xz: OK
```

Similarly for using SHA256 checksum, use the following instructions:

```
$ sha256sum --check arm-gnu-toolchain-13.3.rel1-x86_64-aarch64-none-linux-
gnu.tar.xz.sha256asc
arm-gnu-toolchain-13.3.rel1-x86_64-aarch64-none-linux-gnu.tar.xz: OK
```

Installing on Linux

To install a toolchain on Linux, unpack the tarball to the preferred installation directory using the following instruction:

On x86\_64:

```
$ tar xJf arm-gnu-toolchain-13.3.rel1-x86_64-<TRIPLE>.tar.xz -C /path/to/install/dir
```

On aarch64:

```
$ tar xJf arm-gnu-toolchain-13.3.rel1-aarch64-<TRIPLE>.tar.xz -C /path/to/install/
dir
```

To use GDB, Python 3.8 is required to be installed, and on Ubuntu 20.04 or later you might also need to install libncurses5 or libncursesw5. You might need to install Python 3.8 from source.

The information about installing Python can be found from other sources or websites, unaffiliated to Arm, for example, from docs.python.org, or from [LinuxCapable](#). For GDB to be able to detect the existence of an installed Python 3.8 library on the system, you might also need to set the `PYTHONPATH` and `PYTHONHOME` environment variables. Set `PYTHONHOME` to the location where the Python 3.8 libraries are. For example, if Python 3.8 was installed to `/usr/lib` or `/usr/lib64`, then set `PYTHONHOME=/usr`. In order to find the correct value for `PYTHONPATH`, run `python3.8 -c "import sys; print(sys.path)"` and look for the path ending in `/python3.8`. Set `PYTHONPATH=<that path ending in /python3.8>`.

## Installing on macOS

To install a toolchain on macOS, unpack the tarball to the preferred installation directory using the following instruction:

On darwin-x86\_64:

```
$ tar xJf arm-gnu-toolchain-13.3.rel1-darwin-x86_64-<TRIPLE>.tar.xz -C /path/to/install/dir
```

On darwin-arm64:

```
$ tar xJf arm-gnu-toolchain-13.3.rel1-darwin-arm64-<TRIPLE>.tar.xz -C /path/to/install/dir
```

## Installing on Windows

To install the toolchain on Windows, you may choose to run the installer:

```
arm-gnu-toolchain-13.3.rel1-mingw-w64-i686-<TRIPLE>.exe
```

and follow the instructions. The installer can also be run on the command line. When run on the command-line, the following options can be set:

```
- /S Run in silent mode  
- /P Adds the installation bin directory to the system PATH  
- /R Adds an InstallFolder registry entry for the install.
```

For example, to install the tools silently, amend users PATH and add registry entry:

```
> arm-gnu-toolchain-13.3.rel1-mingw-w64-i686-<TRIPLE>.exe /S /P /R
```

Alternatively, you may use the zip package if you cannot run the installer. In order to do so, you must extract the content of the zip file at a preferred folder.

Arm recommends that you always install into the default installation location. Installing into a different location could expose your system to risks associated with weaker access permissions. For example, the access permissions inherited from the installation directory might allow non-admin

users to modify the installed content. Arm recommends restricting write access, to any custom installation location, to only the users who are allowed to run the installer.

### Known Dependencies

- Using GDB with Python support, on Linux hosts, requires installation of Python3.8, Python3.8-dev or libpython3.8.
- aarch64\_be-none-linux-gnu-gdb and aarch64\_be-none-linux-gnu-gdb-py on Linux hosts requires liblzma.so.5.
- Toolchains dedicated for Windows host require mingw-w64 library, a complete runtime environment for GCC.
- The following executables in the Windows hosted toolchains:
  - aarch64-none-linux-gnu-dwp.exe
  - aarch64-none-linux-gnu-ld.gold.exe
  - arm-none-linux-gnueabi-hf-dwp
  - arm-none-linux-gnueabi-hf-ld.gold.exe

have additional dependencies on the following dlls:

- libwinpthread-1.dll
- libgcc\_s\_sjlj-1.dll
- libstdc++-6.dll
- libgcc\_s\_dw2-1.dll

You can obtain the required dlls from the MinGW-W64 GCC-8.1.0 packages from SourceForge:

- i686-posix-sjlj
- i686-posix-dwarf

### Invoking GCC

On Linux and macOS, either invoke with the complete path like this:

```
$ <install-dir>/arm-gnu-toolchain-13.3.rel1-<HOST_ARCH>-aarch64-none-elf/bin/  
aarch64-none-elf-gcc
```

where, depending on the host, <HOST\_ARCH> is one of:

```
x86_64  
aarch64  
darwin-x86_64  
darwin-arm64
```

Or set the path and then invoke the toolchain like this:

```
$ export PATH=$PATH:<install-dir>/arm-gnu-toolchain-13.3.rel1-<HOST_ARCH>-aarch64-  
none-elf/bin  
$ aarch64-none-elf-gcc --version
```

On Windows, although the above approaches also work, it can be more convenient to either have the installer register environment variables, or run `<install-dir>\bin\gccvar.bat` to set environment variables for the current cmd.

For Windows zip package, after extracting the files, we can invoke the toolchain either using the complete path as follows:

```
<install-dir>\bin\aarch64-none-elf-gcc
```

or run `<install-dir>\bin\gccvar.bat` to set environment variables for the current cmd.

## Architecture Options

This toolchain is built and optimized for Arm processors.

This section describes how to invoke GCC/G++ with the correct command-line options for variants of Cortex-A, Cortex-R and Cortex-M processors.

```
$ aarch64-none-elf-gcc [-mthumb] -mcpu=CPU[+extension...] -mfloat-abi=ABI
```

### -mcpu:

For the permissible CPU names and extensions, see the GCC online manual: <https://gcc.gnu.org/onlinedocs/gcc-13.3.0/gcc/ARM-Options.html#index-mcpu-2>

Use the optional extension name with `-mcpu` to disable the extensions that are not present in the CPU of your choice.

By default, `-mfp=auto` and this enables the compiler to automatically select the floating-pointing and Advanced SIMD instructions based on the `-mcpu` option and extension.

### -mfloat-abi:

If floating-point or Advanced SIMD instructions are present, then use the `-mfloat-abi` option to control the floating-point ABI, or use `-mfloat-abi=soft` to disable floating-point and Advanced SIMD instructions.

For the permissible values of `-mfloat-abi`, see the GCC online manual: <https://gcc.gnu.org/onlinedocs/gcc-13.3.0/gcc/ARM-Options.html#index-mfloat-abi>

### -mthumb:

When using processors that can execute in Arm state and Thumb state, use `-mthumb` to generate code for Thumb state.

### Examples:

Examples with no floating-point and Advanced SIMD instructions:

```
$ arm-none-eabi-gcc -mcpu=cortex-m7+nofp
$ arm-none-eabi-gcc -mcpu=cortex-r5+nofp -mthumb
$ arm-none-eabi-gcc -mcpu=cortex-a53+nofp -mthumb
$ arm-none-eabi-gcc -mcpu=cortex-a57 -mfloat-abi=soft -mthumb
```

Examples with single-precision floating-point with soft-float ABI:

```
$ arm-none-eabi-gcc -mcpu=cortex-m7+nofp.dp -mfloat-abi=softfp
$ arm-none-eabi-gcc -mcpu=cortex-r5+nofp.dp -mfloat-abi=softfp -mthumb
```

Examples with single-precision floating-point with hard-float ABI:

```
$ arm-none-eabi-gcc -mcpu=cortex-m7+nofp.dp -mfloat-abi=hard
$ arm-none-eabi-gcc -mcpu=cortex-r5+nofp.dp -mfloat-abi=hard -mthumb
```

Examples with double-precision floating-point with soft-float ABI:

```
$ arm-none-eabi-gcc -mcpu=cortex-m7 -mfloat-abi=softfp
$ arm-none-eabi-gcc -mcpu=cortex-r5 -mfloat-abi=softfp -mthumb
```

Examples with double-precision floating-point with hard-float ABI:

```
$ arm-none-eabi-gcc -mcpu=cortex-m7 -mfloat-abi=hard
$ arm-none-eabi-gcc -mcpu=cortex-r5 -mfloat-abi=hard -mthumb
```

Example with floating-point and Advanced SIMD instructions with soft-float ABI:

```
$ arm-none-eabi-gcc -mcpu=cortex-a53 -mfloat-abi=softfp -mthumb
```

Example with floating-point and Advanced SIMD instructions with hard-float ABI:

```
$ arm-none-eabi-gcc -mcpu=cortex-a53 -mfloat-abi=hard -mthumb
```

Example with MVE and floating-point with soft-float ABI:

```
$ arm-none-eabi-gcc -mcpu=cortex-m55 -mfloat-abi=softfp
```

Example with MVE and floating-point with hard-float ABI:

```
$ arm-none-eabi-gcc -mcpu=cortex-m55 -mfloat-abi=hard
```

Available multilibs

Arm GNU Toolchain 13.3.Rel1 supports a set of multilibs in each toolchain.



To list all multilibs supported by any of the toolchain, use `--print-multi-lib` option. For example,

```
$ aarch64-none-elf-gcc --print-multi-lib
```

To check which multilib is selected by the arm-none-eabi toolchain based on `-mthumb`, `-mcpu`, `-mfpu` and `-mfloat-abi` command line options:

```
$ aarch64-none-elf-gcc [-mthumb] -mcpu=CPU -mfpu=FPU -mfloat-abi=ABI --print-multi-dir
```

For example:

```
$ arm-none-eabi-gcc -mcpu=cortex-a55 -mfpu=auto -mfloat-abi=hard --print-multi-dir
thumb/v8-a+simd/hard
$ arm-none-eabi-gcc -mcpu=cortex-r5 -mfpu=auto -mfloat-abi=softfp --print-multi-dir
thumb/v7+fp/softfp
$ arm-none-eabi-gcc -mcpu=cortex-m0 -mfpu=auto -mfloat-abi=soft --print-multi-dir
thumb/v6-m/nofp
```

## C Libraries

This section only applies for arm-none-eabi targets.

Arm GNU Toolchain 13.3.Rel1 is released with two prebuilt C libraries based on newlib, for arm-none-eabi target.

One is the standard newlib and the other is newlib-nano for reduced code size. To distinguish them, the nano versions are renamed with `_nano` suffix:

```
libc.a --> libc_nano.a
libg.a --> libg_nano.a
```

To use newlib-nano, users should provide additional gcc compile and link time option:

```
--specs=nano.specs
```

At compile time, a 'newlib.h' header file especially configured for newlib-nano will be used if `-specs=nano.specs` is passed to the compiler.

nano.specs also handles two additional gcc libraries: `libstdc++_nano.a` and `libsupc++_nano.a`, which are optimized for code size.

For example:

```
$ arm-none-eabi-gcc src.c --specs=nano.specs ${OTHER_OPTIONS}
```

This option can also work together with other specs options such as:

```
--specs=rdimon.specs
```

Please note that `-specs=nano.specs` is both a compiler and linker option. Be sure to include in both compiler and linker options if compiling and linking are separated.

Additional newlib-nano libraries usage

Formatted input/output of floating-point number are implemented as weak symbol. If you want to use `%f`, you have to pull in the symbol by explicitly specifying “-u” command option.

```
-u _scanf_float  
-u _printf_float
```

e.g. to output a float, the command line is like:

```
$ arm-none-eabi-gcc --specs=nano.specs -u _printf_float ${OTHER_LINK_OPTIONS}
```

Semihosting

Users can choose to use or not use semihosting by using the following instructions.

If you need semihosting, link as follows:

```
$ arm-none-eabi-gcc --specs=rdimon.specs ${OTHER_LINK_OPTIONS}
```

If you don't need semihosting or if you use retarget, link as follows:

```
$ arm-none-eabi-gcc --specs=nosys.specs ${OTHER_LINK_OPTIONS}
```

Linker scripts & start-up code

This section only applies for arm-none-eabi targets.

Latest update of linker scripts template and start-up code is available on <https://developer.arm.com/tools-and-software/embedded/cmsis>

## Samples

This section only applies for arm-none-eabi targets.

Examples are available at:

```
<install-dir>/share/gcc-arm-none-eabi/samples
```

Read readme.txt under it for further information.

## GDB Server for CMSIS-DAP based hardware debugger

This section only applies for arm-none-eabi targets.

CMSIS-DAP is the interface firmware for a Debug Unit that connects the Debug Port to USB. More detailed information can be found at <http://www.keil.com/support/man/docs/dapdebug/>.

A software GDB server is required for GDB to communicate with CMSIS-DAP based hardware debugger. The pyOCD is an implementation of such GDB server that is written in Python and under Apache License.

For those who are using this toolchain and have a board with CMSIS-DAP based debugger, the pyOCD is our recommended gdb server. More information can be found at <https://github.com/pyocd/pyOCD>.

## Building Linux hosted toolchain from sources using Linaro's ABE

If you would like to build a toolchain yourself using the source revisions used for this release, you can do so using Linaro ABE (Advanced Build Environment) and the provided ABE manifest files.

All the toolchains hosted on linux can be built using the steps provided below, except for the arm-gnu-toolchain-arm-none-eabi toolchain, which has additional steps.

Note that the toolchains built using the Linaro ABE build system are not identical to the released binaries of Arm GNU Toolchain.

In the aarch64-none-elf toolchain built with the Linaro ABE build system, there is a known issue of dependency on getentropy. This known issue is described in [PR103166](#).

The example below shows how to build arm-gnu-toolchain-aarch64-none-elf toolchain using Linaro ABE build system.

### Instructions

1. Install the dependencies ABE has a dependency on git-new-workdir and needs this tool to be installed in /usr/local/bin directory:

```
$ wget https://raw.githubusercontent.com/git/git/master/contrib/workdir/git-new-workdir
$ sudo mv git-new-workdir /usr/local/bin
$ sudo chmod +x /usr/local/bin/git-new-workdir
```

2. Clone ABE from the URL below and checkout the stable branch (see Getting ABE):

```
$ git clone https://git.linaro.org/toolchain/abe.git
```

3. Create the build directory and change to it. Any name for the directory will work:

```
$ mkdir build && cd build
```

4. Configure ABE (from the build directory):

```
$ ../abe/configure
```

5. Download the toolchain manifest file:

Download the toolchain manifest file from [arm Developer download page](https://developer.arm.com/-/media/Files/downloads/gnu/13.3.rel1/manifest/arm-gnu-toolchain-aarch64-none-elf-abe-manifest.txt), into the build folder, for the required toolchain, for example, arm-gnu-toolchain-aarch64-none-elf-abe-manifest.txt:

```
$ wget https://developer.arm.com/-/media/Files/downloads/gnu/13.3.rel1/manifest/arm-gnu-toolchain-aarch64-none-elf-abe-manifest.txt
```

6. Build toolchain (from the build directory):

```
$ ../abe/abe.sh --manifest arm-gnu-toolchain-aarch64-none-elf-abe-manifest.txt --build all
```

The built toolchain will be installed and available for use in the builds/destdir/x86\_64-pc-linux-gnu/bin/ directory.

The example below shows how to build arm-gnu-toolchain-arm-none-eabi from sources using Linaro ABE build system.

#### Instructions

1. Install the dependencies ABE has a dependency on git-new-workdir and needs this tool to be installed in /usr/local/bin directory:

```
$ wget https://raw.githubusercontent.com/git/git/master/contrib/workdir/git-new-workdir
$ sudo mv git-new-workdir /usr/local/bin
$ sudo chmod +x /usr/local/bin/git-new-workdir
```

2. Clone ABE from the URL below and checkout the stable branch (see Getting ABE):

```
$ git clone https://git.linaro.org/toolchain/abe.git
```

3. Create the build directory and change to it:

```
$ mkdir build && cd build
```

4. Configure ABE (from the build directory):

```
$ ../abe/configure
```

5. Download the toolchain manifest file:

Download the toolchain manifest file `arm-gnu-toolchain-arm-none-eabi-abe-manifest.txt` from <https://developer.arm.com/tools-and-software/open-source-software/developer-tools/gnu-toolchain/downloads>, into the build folder:

```
$ wget https://developer.arm.com/-/media/Files/downloads/gnu/13.3.rel1/manifest/arm-gnu-toolchain-arm-none-eabi-abe-manifest.txt
```

6. Build toolchain (from the build directory):

```
$ ../abe/abe.sh --manifest arm-gnu-toolchain-arm-none-eabi-abe-manifest.txt --build all >& log &
```

7. To build toolchain with newlib-nano configuration move out of build directory and create the `build_newlib` directory and change to it:

```
$ cd .. && mkdir build_newlib && cd build_newlib
```

8. Clone ABE from the URL below and checkout the stable branch (see Getting ABE):

```
$ git clone https://git.linaro.org/toolchain/abe.git
```

9. Configure ABE (from the `build_newlib` directory):

```
$ abe/configure
```

10. Download the toolchain manifest file:

Download the toolchain manifest file `arm-gnu-toolchain-arm-none-eabi-nano-abe-manifest.txt` from <https://developer.arm.com/tools-and-software/open-source-software/developer-tools/gnu-toolchain/downloads>, into the `build_newlib` folder:

```
$ wget https://developer.arm.com/-/media/Files/downloads/gnu/13.3.rel1/manifest/arm-gnu-toolchain-arm-none-eabi-nano-abe-manifest.txt
```

11. Build toolchain (from the `build_newlib` directory):

```
$ abe/abe.sh --manifest arm-gnu-toolchain-arm-none-eabi-nano-abe-manifest.txt --build all >& log_nano
```

12. Move out of `newlib_nano` directory and download the `copy_nano_libraries.sh` script:

Download the `copy_nano_libraries.sh` script from <https://developer.arm.com/tools-and-software/open-source-software/developer-tools/gnu-toolchain/downloads>, to the folder above `build_newlib` directory:

```
$ cd .. && wget https://developer.arm.com/-/media/Files/downloads/gnu/13.3.rel1/manifest/copy_nano_libraries.sh
```

13. Copy the newlib nano header and newlib nano libraries build in build\_newlib folder to build folder and change to build folder:

```
$ ./copy_nano_libraries.sh && cd build
```

The built arm-none-eabi toolchain will be installed and available for use in the builds/destdir/x86\_64-pc-linux-gnu/bin/ directory.

### Building the toolchain from sources using gnu-devtools-for-arm

If you would like to build a toolchain yourself using the source revisions used for this release, you can do so using the scripts in the gnu-devtools-for-arm project.

Note that the scripts in the gnu-devtools-for-arm project are meant to rebuild a toolchain that is similar to the released toolchain. The toolchains built using this method are not identical to the released binaries of Arm GNU Toolchain because the scripts used to build the released toolchains, and scripts in the gnu-devtools-for-arm project, are currently in different repositories and might contain different updates.

The instructions for building the toolchain are provided in the [README.md](#) file from the gnu-devtools-for-arm project.